

AQUASAFE®

FLOOD BAGS

Superior Protection Against Indoor Water Damage and Outdoor Flooding

AquaSafe flood bags are a revolutionary way to protect your property against water damage. In minutes they can act as instant sandbags that will soak up to 5.8 gallons per bag, which is equal to 50 pounds of water. They are fast and easy to stack in any configuration to guide rushing or rising water away from valuable property. AquaSafe flood bags can also be used as super-absorbent pads for soaking up leaks and spills, providing valuable protection against property and inventory damage in addition to preventing slips and falls from standing water.

INSTRUCTIONS: SANDBAG

If using AquaSafe as a sandbag or to guide rushing water, follow the instructions below:



Open the plastic bag containing AquaSafe flood bags and remove the bags, taking care not to damage them.



Activate the number of bags you wish to use by soaking the AquaSafe for up to 3 minutes in any of these ways:

- Bucket, wheelbarrow or sink
- Hose or watering can
- Place dry bag down and let rain or floodwater activate the bag



To use as a sandbag: Place activated AquaSafe in layers to build up a barrier on the outside of a property or in front of a door to prevent water from entering.



To use as a water diversion: Place activated Aqua Safe flood bags in piles along the edge of flowing water to direct it away from property.



AquaSafe flood bags are designed for the duration of the incident or can be reused for another event.*

When finished using activated AquaSafe bag, simply dispose of the bag in a trash receptacle.

INSTRUCTIONS: SUPER ABSORBENT

If using AquaSafe as a super-absorbent pad, follow the instructions below:



Open the plastic bag containing AquaSafe flood bags and remove the bags, taking care not to damage them.



Place the dry AquaSafe flood bag in the area where water has pooled, or a leak is expected to occur.



AquaSafe will absorb the liquid and continue to expand until full.



Once AquaSafe is full and cannot absorb any more liquid, simply pick it up and dispose of it in a trash receptacle. The AquaSafe bag will not drip when transporting.



www.buyaquasafe.com
888-533-2994



8 65500 00020 8

*Once activated, AquaSafe bags can be moved around and reused in different locations. If bag starts to dry out, you can add water to reactivate to full capacity.